

Modeļa identifikators

FIDC N665

Piegādātāja nosaukums vai preču zīme

Candy

[M] Built-in / Free standing

Built-in

Product Line

Cepeškrāsnis

Neto svars (kg)

28,2

Energy Efficiency Index, EEI Cav 1

81.7

Energy Efficiency Index, EEI Cav 2

Energoefektivitātes klase - Nodalījumā 1

A+

Energoefektivitātes klase - Nodalījumā 2

0

Energy consumption conventional (kWh) - cavity 1

0.98

Energijas patēriņš parasto (kWh) - nodalījumā 2

0.00

Energijas patēriņš režīmā ar pastiprinātu gaisa konvekciju (kWhy) - nodalījumā 1

0.67

Energijas patēriņš režīmā ar pastiprinātu gaisa konvekciju (kWhy) - nodalījumā 2

0.00

Cepeškrāšņu skaits

1

Energijas patēriņš

electricity

Heat source(s) - cavity 2

-

Tvertnes dobuma tilpums (l) - dobumam 1

65

Tvertnes dobuma tilpums (l) - dobumam 2

Product information for networked equipment as per Regulation (EU) n° 801/2013

Modela identifikators FIDC N665

|                               |   |
|-------------------------------|---|
| Standby power consumption [W] | 1 |
|-------------------------------|---|

Standby power management delay [min]

|                                |  |
|--------------------------------|--|
| Off mode power consumption [W] |  |
|--------------------------------|--|

Off mode power management delay [min]

|                                         |   |
|-----------------------------------------|---|
| Networked standby power consumption [W] | 0 |
|-----------------------------------------|---|

Networked standby power management delay [min]

|                                                                                                                         |  |
|-------------------------------------------------------------------------------------------------------------------------|--|
| Networked standby power consumption with all wired network ports connected and all wireless network ports activated [W] |  |
|-------------------------------------------------------------------------------------------------------------------------|--|

|                                       |   |
|---------------------------------------|---|
| How to activate wireless network port | - |
|---------------------------------------|---|

|                                         |   |
|-----------------------------------------|---|
| How to deactivate wireless network port | - |
|-----------------------------------------|---|